

LUXURY TOPS

VW
AMAROK MK1

2nd EDITION

Revision 1

TRUCKMAN
FITTING INSTRUCTIONS



**Auto
Styling**
TRUCKMAN

www.autostylinguk.com

Please read these instructions carefully. If you have any questions regarding the fitting of this item call 0845 6444704 or email fitting@autostylinguk.com.

Failure to comply with these instructions may affect any warranty considerations

Kit Contents



1 x Truckman Hardtop



6 x Clamp Locks



1 x Wiring Loom




2 x Roof Bars



5 x Scotch Locks

Tools Required

- Allen Keys
- 17 mm Wrench / Socket *(Use a Torque Wrench if possible)*
- Silicon Sealant & Pump
- Drill Driver
- Pair of Pliers
- Multimeter (Recommended)



1 x 20A Fuse



1 x Protective Tape (Roll)



1 x VHB Wipe

- Also includes:
- 1 x Touch Up Paint
 - 2 x Backup Keys





Preparation




3 Temporarily open the pop out windows to remove the foam protection.

4 If fitted, remove the screw at the top of the rubber seals.



7 Tape the hardtop wire temporarily to the roof bars.

8 Thoroughly clean the rear window of the pickup and the hardtop's bulkhead window.



1 Remove the cardboard packaging from around the top. Keep the packaging intact.

2 Remove the fitting kit & roof bars by leaning the hardtop.



5 Assemble roof bars and fit to bosses.


6 In the fitting kit, remove the bolt caps from the clamp locks and completely unscrew each of them.





OVERRAIL BEDLINERS can cause the hardtop to leak due to an uneven surface. Therefore Auto Styling highly recommends converting to or replacing with an underrail bedliner.

- 13** Wipe down the top of the vehicle bed.
- 14** Seal the front corners with silicon sealant. Use clear or black, depending on the vehicle colour.



- 15** Release the brake light cluster from the rear of the cab.
- 16** Unclip the connector and replace the light fitting.

Fitting

- 1** Lift the hardtop onto the bed.



- 2** Loosely fit the clamps in between the gaps in the black rubber strip



- 3** Align the top centrally on the bed. Ensure there is a good gap between the hardtop and the vehicle cab, and that the seal under the hardtop door is just touching the tailgate or bedliner.



NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com


! **IMPORTANT:** Door and tailgate **MUST** be closed for step 4.

4 Tighten the clamps to 8Nm Torque using the 17mm wrench (Start with the middle clamps).



(Just more than hand tight / 8Nm Torque)

5 Replace the bolt caps onto the clamps.



6 Clean the top edge of tailgate using the VHB wipe supplied or a good quality bodywipe.

7 Remove the roll of tape from the bag and cut one end square.

8 Partly remove the backing from the tape.



9 Apply it to the tailgate, rubbing outwards to remove any bubbles as you go.

10 Cut the other end square.

Electrics




1 Ensure the ignition is off. Remove door sill trim and seal from the driver's door.

2 Remove the handle and pillar trim from front, right hand pillar.


Be careful of the wire going to the ultrasonic sensor.

3 Connect the wiring loom to the hardtop.

4 Take the wiring loom from the fitting kit and pass the '5-wire' leg through this grommet (under the driver's seat), into the cab.



- 5 In the door sill, expose the wires and locate the central locking wires.
- 6 In the pillar loom, expose the wires and locate the heated screen wire and the brake light wire
- 7 Using the provided scotch locks (or similar method), fix the loom as shown.



Vehicle wire colours are listed as a guide only.

It is imperative that you check with a multi-meter them before connecting the wiring harness.

HARDTOP COLOURS

- YELLOW**
- GREY**
- BROWN**
- GREEN**
- BLUE**

CONNECTED TO THE VEHICLE'S


- CENTRAL LOCKING (LOCK)
- CENTRAL LOCKING (UNLOCK)
- NOT USED
- HEATED SCREEN
- BRAKE

EXPECTED VEHICLE COLOURS

- YELLOW**
- WHITE**
- NOT USED
- WHITE**
- BLACK RED**


NOTES

Checked on a 12 Plate Mk1 Amarok
Door switch needs to be held down, but these wires flash 12V using the remote
 Not available on this vehicle.
12V when the heated screen is on
12V when brake pedal depressed




- 7 Bring the other leg of wires (including relay) under the vehicle, into corner of the engine compartment (avoiding heat sources).
- 8 Bring the wires across the front of the engine bay to the battery (wrap around existing vehicle wires to keep away from engine. Extension may be necessary).

- 9 Attach the **BLACK** wire to the earth post on the battery and the **RED** wire to the live post on the battery.
- 10 Insert the fuse into the fuse holder.




NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com




- 11 Open the hardtop door. Ensure the light is set to "Door" and that the interior light is on. Close the door and check it switches off.
- 12 Press the brake pedal to check the brake light is on. Use reflective surfaces or a second person.


- 13 Use a multimeter to confirm a current across the heated rear window when on.



- 14 Check that the hardtop locks and unlocks with the vehicle's remote.



- 15 Apply silicon to grommet from step 4. Replace all door trim and cable tie all external wire to the chassis. Close all doors and the bonnet.



- 16 Repeat steps 17-20 to check everything still works.

IMPORTANT NOTES



The hardtop is designed to rely on the vehicles central locking. It should open and lock with the vehicle's key fob. The included keys are intended to work as a backup, should the central locking fail.

The keys CANNOT be removed once turned 180° to ensure the hardtop cannot be left unintentionally unlocked.



NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com

Notes

Lined area for notes, consisting of 22 horizontal lines.

Stainless Steel Styling

Add that extra style and protection to your Amarok with stunning stainless steel accessories, such as this A-Bar.



IMPORTANT NOTES

Bedliners **must** be underrail for a good fit.
Ensure the tailgate and side windows are closed when driving.
Do not place animals in the load area without adequate ventilation.
Do not exceed the load limit on the roof rails
(See sticker on the hardtop)

MAINTENANCE

Use a light oil to lubricate the lock and hinges.
Check the tightness of the fixing clamps / bolts.
(Just more than hand tight / 8Nm Torque)

CLEANING

Use ordinary non-ammonia based car cleaning products and a soft or microfibre cloth.

IMPORTANT NOTES



The hardtop is designed to rely on the vehicles central locking. It should open and lock with the vehicle's key fob. The included keys are intended to work as a backup, should the central locking fail.

The keys CANNOT be removed once turned 180° to ensure the hardtop cannot be left unintentionally unlocked.



Auto Styling UK Limited,
Unit 4 Narrowboat Way, Hurst Business Park, Brierley Hill, DY5 1UF, UK
Tel: 0845 6444704 Fax: 0845 64445014
Email: fitting@autostylinguk.com

www.autostylinguk.com

Notice

It is important that safety warnings in the instructions are adhered to.

Do not attempt to fit this product if you are not competent to do so. Improper fitting may affect your warranty considerations. For your safety, we recommend that any wiring is performed by qualified Auto Electricians.

Due to tolerances of the vehicle fitting of this product may differ from the exact fitting specifications described in the instructions. It is the responsibility of the fitter that the product is installed correctly.

Fitting instruction revisions may be found at www.autostylinguk.com