

LUXURY TOPS

NISSAN
NAVARA D40 MK1-2

REVISION 4

TRUCKMAN
FITTING INSTRUCTIONS










**Auto
Styling**
TRUCKMAN

www.autostylinguk.com

Please read these instructions carefully. If you have any questions regarding the fitting of this item call 0845 6444704 or email fitting@autostylinguk.com.

Failure to comply with these instructions may affect any warranty considerations

| Kit Contents | | | | Tools Required |
|--|---|---|---|---|
|  |  |  |  | Medium Philips Screwdriver 17 mm Wrench / Socket <i>(Use a Torque Wrench if possible)</i> Silicon Sealant & Pump Drill Driver Pair of Pliers Multimeter (Recommended) |
| 1 x ASX Hardtop | 6 x Clamp Locks | 1 x Wiring Loom | 5 x Scotch Locks | |
|  |  |  | | |
| 1" Double Sided Tape | 1 x 20A Fuse | 1 x Touch Up Paint | | |

Preparation




- 1 Remove the cardboard packaging from around the top. Keep the packaging intact.
- 2 Remove the fitting kit and close the bulkhead window.

- 3 Open the pop out windows to remove the foam protection. Then close the windows.
- 4 Unscrew the screw at the top of the rubber seals.



- 5 Tape the hardtop wire temporarily to the roof bars.
- 6 In the fitting kit, remove the bolt caps from the clamp locks and completely unscrew each of them.

- 7 Thoroughly clean the rear window of the pickup and the hardtop's bulkhead window.



NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com



OVERRAIL BEDLINERS can cause the hardtop to leak due to an uneven surface. Therefore Auto Styling highly recommends converting to or replacing with an underrail bedliner.

For instructions, visit our website at www.autostylinguk.com/info/fitting-instructions/



8 Wipe down the top of the vehicle bed and seal the front corners with silicon sealant. Use clear or black, depending on the vehicle colour.

Fitting

1 Lift the hardtop onto the bed.



HEAVY LIFTING

At least 3 people required for lifting




2 Loosely fit the clamps, cutting gaps in the black rubber strip.



3 Align the top centrally on the bed. Ensure there is a gap between the hardtop and the vehicle cab, and that the seal under the hardtop door is just touching the tailgate or bedliner.

4 With the door shut, tighten the clamps to 10Nm Torque using the 17mm wrench (Start with the middle clamps).

5 Replace the bolt caps onto the clamps.



(Just more than hand tight / 10Nm Torque)



Please read these instructions carefully. If you have any questions regarding the fitting of this item call 0845 6444704 or email fitting@autostylinguk.com.

Failure to comply with these instructions may affect any warranty considerations

Electrics

! Vehicle wire colours are listed as a guide. Please check with a multi-meter before fitting the harness.





- 1 Ensure the ignition is off. Remove door sill trim and kick plate from the driver's door.
- 2 Drill a suitably sized hole in the vehicle's floor pan. We use a bore hole drill bit. Connect the wiring loom from the fitting kit to the hardtop.

- 3 Pass the '5-wire' leg through the hole, into the cab.
- 4 Slide a grommet down the wire and into the hole. Pass the wire to the front and fill the grommet with silicon sealant. Disconnect the hardtop.



- 5 In the driver's door sill, expose the wires and locate the central locking wires (**PURPLE** (lock) & **WHITE** (unlock)), the heated rear screen wire (**BLACK**), the door switch wire (**TURQUOISE**), and the brake wire (above brake pedal - see left, **YELLOW**).



- 6 Using the scotch locks, fix the loom as shown.

| | |
|----------------|----------------------|
| HARDTOP | VEHICLE |
| YELLOW | LOCKING |
| GREY | UNLOCKING |
| GREEN | HEATED SCREEN |
| BROWN | DOOR SWITCH |
| BLUE | BRAKE |

- 7 Bring the other leg of wires (including relay) under the vehicle, into the engine compartment.
- 8 Attach the relay to the side of the vehicle's fuse box using the double sided sticky tape.



Please read these instructions carefully. If you have any questions regarding the fitting of this item call 0845 6444704 or email fitting@autostylinguk.com.

Failure to comply with these instructions may affect any warranty considerations

Additional Fitting

- 1 Remove the roll of tape from the bag.



- 2 Cut one end of the tape square.

- 3 Partly remove the backing from the tape.



- 4 Carefully apply it to the tailgate, rubbing outwards to remove any bubbles as you go.



- 5 Trim the tape square at the other end.



NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com



Auto Styling UK Limited,
 Unit 4 Narrowboat Way, Hurst Business Park, Brierley Hill, DY5 1UF, UK
 Tel: 0845 6444704 Fax: 0845 64445014
 Email: fitting@autostylinguk.com

www.autostylinguk.com

Notice

It is important that safety warnings in the instructions are adhered to. Do not attempt to fit this product if you are not competent to do so. Improper fitting may affect your warranty considerations. For your safety, we recommend that any wiring is performed by qualified Auto Electricians. Due to tolerances of the vehicle fitting of this product may differ from the exact fitting specifications described in the instructions. It is the responsibility of the fitter that the product is installed correctly. Fitting instruction revisions may be found at www.autostylinguk.com

Page Intentionally Left Blank

INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET

INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET

Page Intentionally Left Blank

Page Intentionally Left Blank

Page Intentionally Left Blank




Page Intentionally Left Blank

INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET

INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET INSERT SHEET

Page Intentionally Left Blank

- 9 Attach the **BLACK** wire to the earth post on the battery and the **RED** wire to the live post on the battery.
- 10 Insert the fuse into the fuse holder and connect the wiring loom to the hardtop.





- 11 Open the hardtop door. Ensure the light is set to "Door" and that the interior light is on. Close the door and check it switches off.
- 12 Press the brake pedal to check the brake light is on. Use reflective surfaces or a second person.

- 13 Use a multimeter (if available) to confirm a current across the heated rear window when on.



- 14 Check that the hardtop locks and unlocks with the vehicle's remote.



- 15 Replace all door trim and cable tie all external wire to the chassis. Close all doors and the bonnet.
- 16 Repeat steps 11-14 to check everything still works.



NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com



Chrome Styling

Add that extra style and protection to your Navara with stunning Chrome accessories.

IMPORTANT NOTES

Bedliners **must** be underrail for a good fit. Ensure the tailgate and side windows are closed when driving.
Do not place animals in the load area without adequate ventilation.
Do not exceed the load limit on the roof rails
(See sticker on the hardtop)

MAINTENANCE

Use a light oil to lubricate the lock and hinges. Check the tightness of the fixing clamps / bolts.
(Just more than hand tight / 10Nm Torque)

CLEANING

Use ordinary non-ammonia based car cleaning products and a soft or microfibre cloth.



NEED ADVICE?

Call our experts on 0845 6444704 or email fitting@autostylinguk.com

Auto Styling

TRUCKMAN

Auto Styling UK Limited,

Unit 4 Narrowboat Way,
Brierley Hill,
West Midlands,
DY5 1UF, UK

Tel: 0845 6444704

Fax: 0845 64445014

Email: fitting@autostylinguk.com

www.autostylinguk.com

Notice

It is important that safety warnings in the instructions are adhered to. Do not attempt to fit this product if you are not competent to do so. Improper fitting may affect your warranty considerations. For your safety, we recommend that any wiring is performed by qualified Auto Electricians.

Due to tolerances of the vehicle fitting of this product may differ from the exact fitting specifications described in the instructions. It is the responsibility of the fitter that the product is installed correctly.

Fitting instruction revisions may be found at www.autostylinguk.com



Remote V2