








➤ Instructions

Thule EuroRide 940, 941



i



i



40 kg

50 kg

>55 kg




14,2 kg

Max 25,8 kg


Max 35,8 kg

Max 36 kg

1




2




3

 x2
  Ø20x4mm x2
  Ø16x1.5mm x4
  x2
  x1
  x1




4

 x2
  x4
  x4






5

 x2
 Ø20x2.5mm
 x2
 x2









6











8




9




10










Thule Bike Frame Adapter
982



i







i








i

940: 13-pin



941: 7-pin





EN Accessories

DE Zubehör

FR Accessoires

NL Accessoires

IT Accessori

ES Accesorios

PT Acessórios

SV Tillbehör

DK Tilbehør

NE Tilbehør

FI Lisävarusteet

ET Lisavarustus

LV Piederumi

LT Priedai

PL Akcesoria

RU Аксессуары

UK Аксессуары

BG Принадлежности

CS Dopřloky

SK Príslušenstvo

SL Dodatki

HR/BiH Dodaci

RO Accesorii

HU Tartozékok

EL Εξαρτήματα

TR Aksesuarlar

AR الملحقات

HE אביזרים

ZH 附件


JA アクセサリー

KO 액세서리

TH อุปกรณ์เสริม


Thule Adapter 9906

7-to-13 pin Adapter



Thule Adapter 9907

13-to-7 pin Adapter




Thule Lockable Knob

526




Thule Wall Hanger

9771




Thule Bike Frame Adapter

982



Thule 3rd Brake Light

9904




Thule Wheel Adapter

9772




Thule Number Plate

9762



Thule One-Key System



544 (x4)

596 (x6)

588 (x8)

452 (x12)